

Emerson Inspire™

1HDEZ-1521

Installation Instructions



Thermostat/Interface

Equipment Control

White
Rodgers.


EMERSON
Climate Technologies

FAILURE TO READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLING OR OPERATING THIS CONTROL COULD CAUSE PERSONAL INJURY AND/OR PROPERTY DAMAGE.

⚠ CAUTION

To prevent electrical shock and/or equipment damage, disconnect electric power to system at main fuse or circuit breaker box until installation is complete.

⚠ WARNING

Thermostat installation and all components of the control system shall conform to Class II circuits per the NEC code.

ATTENTION: MERCURY NOTICE

This product does not contain mercury. However, this product may replace a product that contains mercury.

Mercury and products containing mercury must not be discarded in household trash. Do not touch any spilled mercury. Wearing non-absorbent gloves, clean up any spilled mercury and place in a sealed container. For proper disposal of a product containing mercury or a sealed container of spilled mercury, place it in a suitable shipping container. Refer to **www.thermostat-recycle.org** for location to send product containing mercury.

Index	Page
Applications and Specifications	3
Installation	4
Advanced Installer Menu	12
Main Menu	20
Troubleshooting	26

Applications and Specifications

Configuration Options	Applications	Maximum Stages
Single Stage	Gas, Oil, Electric, Heat Only, Cool Only or Heat Cool Systems	1/1
Multi Stage	Gas, Oil, Electric, Heat Only, Cool Only or Heat Cool Systems	2/2
Heat Pump	Single or Two Compressor Systems with up to 2 Stages of Aux / Em Heat	4/2
Heat Pump with Dual Fuel	Single or Two Compressor Systems with up to 2 Stages of Fossil fuel Heat	4/2

Electrical Rating:

Input-Hardwire.....	20 to 30 VAC
Terminal Load	1.0A per terminal, 2.5A maximum all terminals combined
Setpoint Range	45° to 99°F (7° to 37°C)
Differential (Single Stage)	Heat 0.6°F; Cool 1.2°F
Differential (Multi-Stage)	Heat 0.6°F; Cool 1.2°F
Differential (Heat Pump)	Heat 1.2°F; Cool 1.2°F
Operating Ambient	32°F to +105°F (0° to +41°C)
Operating Humidity	90% non-condensing max.
Shipping Temperature Range	-40° to +150°F (-40° to +65°C)
Dimensions Interface	3-1/4"H x 6-1/8"W x 5/8"D
Dimensions Control.....	5-1/2"H x 5-3/4"W x 1-1/2"D

Installation

Reduce installation time with a USB

1. Go to **www.white-rodgers.com**
2. Enter 1HDEZ-1521 in the Model Number Search field
3. Select the link for the USB download tool and follow instructions

Upload pre-configured thermostat settings for every job!



Create custom messages for your routine maintenance and service calls!




Installation

Equipment Control

Mount on wall or exterior surface of HVAC equipment. Control has four mounting holes. Wall anchors and screws are provided for mounting on dry-wall. Drill 3/16" hole for drywall mounting.

If mounting on equipment **Do Not Mount** inside HVAC equipment. Only mount on outside of HVAC equipment.




Gas Furnace Equipment

Installation

Equipment Control Terminals	Operation / Function
R.....	24 VAC Transformer
RC.....	24 VAC Cooling Transformer*
RH.....	24 VAC Heating Transformer*
C.....	24 V Transformer Common
W/E.....	Heating Stage 1 HP Aux/Em Heat Stage 1
W2.....	Heating Stage 2 HP Aux/Em Heat Stage 2
Y.....	Compressor Stage 1
Y2.....	Compressor Stage 2
G.....	Fan Relay
L Terminal.....	System Monitor Compatible with Comfort Alert Diagnostics
O/B Terminal.....	Changeover Relay Heat Pump
DHM.....	Dehumidification Relay / Connection
DHM2.....	Dehumidification Relay / Connection
HM.....	Humidification Relay / Connection
HM2.....	Humidification Relay / Connection
R.....	24 VAC to Interface
1.....	Data to/from Interface
2.....	Data to/from Interface
C.....	24 VAC Common to Interface
RJ11.....	Field configuration hook-up with RJ11 equipped configuration tool
+.....	Voltage to Outdoor Sensor
S.....	Outdoor Sensor Temperature Signal
-.....	Voltage to Outdoor Sensor

*For 2 transformer systems, cut and tape off one transformer. If transformer safety circuits are only in one of the systems, remove the transformer of the system with NO safety circuits. If required, replace remaining transformer with a 75 VA Class II transformer. After disconnecting one transformer, the two commons must be jumpered together.

Installation



* To use the HVAC transformer to power humidification/dehumidification switch HM/DHM switches to "SYS" position:

- Connect humidifier to HM
- Connect dehumidifier to DHM

If humidifier or dehumidifier have a separate transformer, switch HM or DHM switch to "DRY" position:

- Connect humidifier to HM and HM2 (or)
- Connect dehumidifier to DHM and DHM2

Installation

Fig. 1 - Typical Connection of a Single Stage or Multi-Stage System





Fig. 2 - Typical Connection of Heat Pump System up to 4 Stages Heat/2 Stages Cool



Note: Dual fuel systems W/E is fossil fuel 1st stage and W2 is fossil fuel 2nd stage.

Installation

Wiring Guide for Equipment Accessories

Fig. 3 - Humidifier. HM terminal provides system 24V on call for humidification




Fig. 4 - Powered Humidifier. With HM DRY switch in HM2 position, HM and HM2 provide normally open dry contact for low voltage (24V) powered humidifier connection.





Fig. 5 - Powered Dehumidifier. With DHM DRY switch in DHM2 position, DHM and DHM2 provide normally open dry contact for low voltage (24V) whole house powered dehumidifier connection.



Installation

Wiring Guide for Equipment Accessories


Fig. 6 - System Dehumidification with variable speed blower. For systems where low speed requires connect to normally open 24V powered DHM terminal for low speed connection on air handler/furnace (24V removed on dehumidification call).



Fig. 7 - System Dehumidification with variable speed blower. For systems where low speed requires system 24V on dehumidification connect 24V to DHM2 with DHM DRY switch in DHM2 position and connect DHM to low speed connection on air handler/ furnace.



Installation




Thermostat


- 1) Pull the thermostat off the base using tabs shown above.
- 2) Place base over wire hole in wall and mark mounting hole locations using base as a template. Drill mounting holes.
- 3) Fasten base snugly to wall using wall anchors and two mounting screws. Leveling is for appearance only and will not affect thermostat operation.
- 4) Connect wires to terminal block on base.
IMPORTANT: Wiring from equipment control should correspond with wiring to thermostat. (see Fig. 8)
- 5) Carefully line the thermostat up with the base and snap into place.

Installation


Fig. 8 - Thermostat and Equipment Control Wiring



Thermostat Base



Equipment Control




Thermostat

Equipment Control

Power System

Turn on AC power to the system. As the equipment module is found, the display will show **"Equipment Control"** found. If the system continues searching after a couple of minutes, check system wiring.



Advanced Installer Menu

From the Home screen press the ◀ and ▶ buttons at the same time for three seconds.

Press **Enter** button to save any changes and display the previous menu or press **Home** to display the Home Screen.

Items on the **Advanced Installer Menu** are:

- Communicating Devices – select system configuration options
- Fault Status – indicates equipment faults that have been detected
- USB Upload – select thermostat settings to be uploaded from a pre-loaded USB
- Thermostat Summary – indicates software version of thermostat
- Heat Pump Lockout* – disable heat pump below a selectable temperature (when using electric Aux heat)
- Dual Fuel Setpoint* – disable heat pump below a selectable temperature (when using fossil fuel Aux heat – dual fuel)
- Aux Lockout* – disable Aux heat above a selectable temperature
- Heat Cycle Rate – adjust the duration for a call for heating
- Cool Cycle Rate – adjust the duration for a call for cooling
- Humidity Display Adjust – off-set the humidity that is displayed
- Installation Test – equipment test for communicating systems only

*May or may not appear in the list depending on the configuration of the system


IMPORTANT: Allow up to 5 minutes for menu options to become available after changing settings.

Advanced Installer Menu


Communicating Devices

This menu item will list each piece of system equipment.


Press **M** button to select start
Communicating Devices.



Press **M** button to select
Equipment Control.




Press **M** button to select **Setup.**



Advanced Installer Menu

Use ▲ or ▼ to navigate and press **M** button to select the equipment to be configured.



Options for each type of equipment are the following:

Indoor

- GA2 – 2 stage gas furnace
- GA1 – 1 stage gas furnace
- EL2 – 2 stage electric heat
- EL1 – 1 stage electric heat
- FAN – Indoor fan only



ADVANCED
INSTALLER MENU

Outdoor

- AC2 – 2 stage A/C unit
- AC1 – 1 stage A/C unit
- HP2 – 2 stage heat pump
- HP1 – 1 stage heat pump
- ACO – no outdoor equipment



Rev Valve

- O – use if “O” wire is available (energize the reversing valve in cooling)
- B – use if “B” wire is available (energize the reversing valve in heating)

Advanced Installer Menu

HUM

OFF – No humidifier equipment

SYS – Humidifier, powered using 24V from system

IND – Humidifier, powered using independent 24V source

DHM

OFF – No dehumidifier equipment

SYS – Dehumidifier, powered using 24V from system

IND – Dehumidifier, powered using independent 24V source

LEDs on the control indicate the thermostat configuration. Remove control cover to view LEDs. To view LEDs with cover installed, break off tab on inside of cover.




Fig. 9 – LED locations

LED Color	
Orange	Green

Indoor	GAS	ELEC
W/E		
W2		
G		

Outdoor	AC	HP
Y		
Y2		

Humidification	HM2	RH
HM		

Dehumidification	DHM2	RH
DHM		


Rev Valve	B	O
O/B		

LED Off implies functionality is disabled at the thermostat
 LED flashing implies corresponding function is active

Advanced Installer Menu

Faults Status

This menu item lists current equipment fault conditions. If no faults are detected, this screen will show nothing. (See “System Fault Codes” on page 28.)



USB Upload


The **USB Upload** menu displays a list of thermostat parameters that can be loaded to the thermostat from a USB memory device. If the USB port detects a USB memory device, this menu will automatically display.

In the **USB Upload** menu, select the item to upload and press **M** to mark the item with a red box. After all items to upload are selected, press the **Upload** button.

If the thermostat does not find information when the Upload button is pressed, the display will indicate, **“Invalid Data Found. Installation Failed!”**

Once the upload is accomplished, the display will indicate **“Successfully Installed”** for 3 seconds then will display the menu or mode prior to entering the USB upload menu.


To use the USB Upload feature, go to www.white-rodgers.com, enter 1HDEZ-1521 in the Model Number Search field and select the USB download link.



Advanced Installer Menu

Thermostat Summary

Indicates the thermostat's software and version.




Heat Pump Lockout (outdoor sensor required)

Available only for heat pump systems with indoor electric heat. This feature disables the heat pump and turns on auxiliary heat below the selected outdoor temperature. The temperature range is from 5° to 50°F.

Dual Fuel Setpoint (outdoor sensor required)

If the heating system is a heat pump with auxiliary gas heat and the outdoor sensor is installed, the thermostat can monitor outside temperature to determine when to begin using the gas heat system and stop the compressor. This temperature is the Dual Fuel temperature setpoint. The Dual Fuel feature eliminates the need for a fossil fuel kit.



The display will indicate 5° (default). The temperature can be adjusted to a value between 5° to 50°. The temperature will appear as °F unless °C is selected for temperature display.

As long as the outside temperature is above the Dual Fuel Setpoint, the compressor will operate. When the temperature drops below the setting the thermostat will start the gas heat and shut off the compressor.


Advanced Installer Menu

Aux Lockout Temperature (outdoor sensor required)

Available for heat pump systems. This setting is the maximum outdoor temperature that is acceptable for auxiliary heat to be used.


Heat Cycle Rate

Anticipation for heat cycle can be adjusted. Default setting is **Medium**. If you wish to have longer heat cycles, change to **Slow**. For shorter heat cycles change to **Fast**.




Cool Cycle Rate

Anticipation for cool cycle can be adjusted. Default setting is **Medium**. If you wish to have longer cool cycles, change to **Slow**. For shorter cool cycles change to **Fast**.



Humidity Display Adjust

Press \blacktriangle or \blacktriangledown to offset the displayed humidity from the actual.



Advanced Installer Menu

Installation Test

Performs an equipment test to verify proper installation and performance.

Only operable on communicating systems with ClimateTalk™.



Check System Operation

Heating System

1. Press SYSTEM button until **Heat** is displayed.
2. Press ▲ to adjust thermostat setting 1° above room temperature. The heating system should begin to operate and the display will indicate **Heat On**.
3. If the heating system has additional stages, adjust the thermostat setting to 3°F (2°C) or more above the actual temperature. The next heat stage will energize.
4. Press ▼ to adjust thermostat setting below room temperature. The heating system should stop operating.

Cooling System

1. Press SYSTEM button until **COOL** is displayed.
2. Press ▼ to adjust thermostat setting below room temperature. The cooling system should begin to operate and the display will indicate **Cool On**.
3. If the cooling system has additional stages, adjust the temperature to 3°F (2°C) or more below the actual. The second cool stage will energize within 10 seconds.
4. Press ▲ to adjust thermostat setting above room temperature. The cooling system should stop operating.

Fan Operation


1. Press FAN button until **Fan On** is displayed. The fan should begin to operate.
2. Press FAN button to change the display to **Fan Auto**. The fan should stop operating as long as there is no call for heat or cool.

Main Menu

Navigating through your thermostat menus

Your thermostat features a simplified easy to understand menu structure.

- Press **M** to enter the Main Menu
- Highlight a menu item using the **▲** or **▼** buttons
- Enter the item by pressing **M**
- Use the **◀** or **▶** and the **▲** or **▼** to change menu items and settings
- Press the **Home** button to display the Home Screen.
- Press the **Enter** button to save any changes you have made and display the previous menu item.
- **If no button is pressed for two minutes, you will return to the home screen without saving changes.**




Clock and Display Settings

Time and Date

Select and enter the time and date to be displayed.

Display Settings

Adjust the brightness and color theme for the display. Turn the keypad backlight and auto-dimmer, on or off.



Main Menu

Time and Day Display

When turned on, the current time and day are displayed on the home screen.

Outdoor Temp Display

When turned on, the outdoor temperature is displayed on the home screen (for use with outdoor sensor only).

Humidity Display


When turned on, the sensed humidity is displayed on the home screen.

Alert Info Detail

When turned on, provides additional information for maintenance and service reminders.

Heating Program

- On the **Main Menu**, highlight and enter **Heating Program**
- Select the days of the week to be changed.
- Press ▲ or ▼ to change the highlighted Time or Temperature to your desired settings
- Press ◀ or ▶ to highlight the next time or temperature
- Set all times and temperatures for all periods



Main Menu

- When you have completed setting all times and temperatures, press **Enter** to save and display the **Heating Program** menu. A checkmark appears to indicate the portion of schedule you have programmed

Cooling Program

After entering Heating Program, press **▶** to highlight “**Switch to Cool Program**” and press **M**, or enter **Cooling Program** on the **Main Menu**.


Factory Pre-Programmed Heating and Cooling Schedule

	Wake Up (Morning)		Leave for Work (Day)		Return Home (Evening)		Go to Bed (Night)	
Heating Program	6:00 AM	70°F	8:00 AM	62°F	5:00 PM	70°F	10:00 PM	62°F
Cooling Program	6:00 AM	75°F	8:00 AM	83°F	5:00 PM	75°F	10:00 PM	78°F

Thermostat Settings


Additional thermostat operating settings are found in the Thermostat Settings Menu.

In the Main Menu highlight and enter **Thermostat Settings**.



Main Menu

Program – Default is **On**. Select **Off** to disable the heating and cooling programs and maintain a constant temperature 24 hours a day.




Air Filter Maintenance / Service Reminder / Humidifier Maintenance


Default for each is **Off**. When set to **On**, a maintenance reminder will appear on the home screen when the system has run for the selected amount of time.

The length of time for the maintenance reminder can be selected to a setting of 1 to 12 months.

Use ▲ or ▼. to select On or Off. When On is selected, set time of maintenance period using ◀ and ▶.



°F or °C – Default is **°F**. Select temperature display to be Fahrenheit or Celsius.




Main Menu


Beeper – Default is **On**. Turns audible prompt on to indicate when a button is pressed.



Cycle Humidifier – Default is **Off**. This feature provides an option that reduces the water usage by up to 50% when a flow-through humidifier is controlled by the thermostat. It is recommended for use on flow-through humidifiers only. When turned **On**, the humidifier will cycle to turn off for 10 minutes after it has run for 10 minutes. The blower and/or furnace will continue to run during the humidifier off period.



Auto Humidity Reduction – Default is **Off**. Prevents condensation from forming inside the home when the HVAC system is in heat mode. The **Low** setting provides a minimum amount of humidity reduction and the High setting provides a maximum.




Main Menu

Comfort or Dehum – Default is Off.


Selecting either **Comfort** or **Dehum** will automatically reduce indoor humidity with a call for cooling if humidity is 2% above the humidity setpoint. If **Comfort** is selected, the system will slow the fan speed (variable speed blowers only) to increase the dehumidification process and cool based on the temperature

setpoint. If **Dehum** is selected, the system makes the dehumidification a priority over temperature. This setting uses more energy and may over-cool the space by up to 3° to achieve the desired humidity level. If **Off** is selected the system will control temperature to the cooling setpoint.




EMR (Energy Management Recovery)

Default is **On**. With EMR selected **On**, the heating or cooling system will start early so the temperature in your home is at the desired temperature at the beginning of the program period. If set to **Off**, the system will not start until the beginning of the program period.




Maximum Heat Setpoint Temp.

Default is **99°**. **Minimum Cool Setpoint Temp.** – Default is **45°**. These settings are the highest temperature limit in **Heat** mode or the lowest temperature limit in **Cool** mode. Select a setting of **99°** to **45°** for the maximum heating temperature or **45°** to **99°** for the minimum cooling temperature.




Main Menu

Temperature Display Adjust – Default is **0°**. Your thermostat was accurately calibrated at the factory. However, this option allows you to change the humidity or temperature displayed to match other thermostats in your home.




Dehumidification Setpoint – Default is **95%**. Setpoint is the percent humidity that the cooling system will attempt to maintain. Only available when dehumidification equipment is enabled (see **Communicating Devices** in **Advanced Installer Menu**).



Humidity Setpoint – Default is **20%**. Humidity setpoint is the percent humidity that the heating system and humidifier will attempt to maintain in Heating.

Only available when humidification equipment is enabled (see **Communicating Devices** in **Advanced Installer Menu**).





Troubleshooting

Reset Operation

If a voltage spike or static discharge blanks out the display or causes erratic thermostat operation, you can reset the system by performing a power reset.

Note: Be sure to record the user's Main Menu settings.

When thermostat is reset, Main Menu and Programming will reset to factory settings. (Installer's equipment setup options will NOT be affected by the reset.)

To reset the programming, clock and configuration settings, press  and  and the **SYSTEM** touch keys simultaneously and hold until the screen resets.

Symptom	Possible Cause	Correction Action
No Heat/No Cool/ No Fan (common problems)	<ol style="list-style-type: none">1. Blown fuse or tripped circuit breaker.2. Power switch to OFF.3. Furnace blower compartment door or panel loose or not properly installed.4. Loose connection to system.	<p>Replace fuse or reset breaker.</p> <p>Turn switch to ON.</p> <p>Replace door panel in proper position to engage safety interlock or door switch.</p> <p>Check connections at the thermostat and equipment control. Thermostat base should be installed on a flat surface to ensure a good connection with the thermostat.</p>
No Heat	<ol style="list-style-type: none">1. Pilot light not lit.2. Furnace Lock-Out Condition. Heat may also be intermittent.3. Heat pump system requires service.	<p>Re-light pilot.</p> <p>Many furnaces have safety devices that shut down when a lock-out condition occurs. If the heat works intermittently contact the furnace manufacturer.</p>

Troubleshooting

Symptom	Possible Cause	Correction Action
No Cool	1. Cooling system requires service.	
Heat, Cool or Fan Runs Constantly	<ol style="list-style-type: none"> 1. Possible short in wiring. 2. Possible short in thermostat. 3. Possible short in heat/cool/fan system. 4. FAN Switch set to Fan ON. 	<p>Check each wire connection to verify they are not shorted or touching together. No bare wire should stick out from under terminal block.</p> <p>Try resetting the thermostat as described above. If the condition persists, the manufacturer of your system can instruct you on how to test the Heat/Cool system for correct operation. If the system operates correctly, replace the thermostat.</p>
Displayed Thermostat Reading and Thermometer Disagree	1. Thermostat display setting requires adjustment.	The display can be adjusted +/- 5 degrees. Adjust the Temperature Display Adjust settings within Thermostat Settings (see Main Menu options).
Furnace (Air Conditioner) Cycles Too Fast or Too Slow (narrow or wide temperature swing)	1. The location of the thermostat and/or the size of the Heating System may be influencing the cycle rate.	Adjust the Heat Cycle Rate or Cool Cycle Rate in the Advanced Installer Menu.

Troubleshooting

Equipment Control Fault Codes

Number Displayed in 7 Segment LED	Comfort Alert Fault
P	Trip
1	Long Run Time
2	System Pressure Trip
3	Short Cycling
4	Locked Rotor
5	Open Circuit
6	Open Start Circuit
7	Open Run Circuit
8	Welded Contactor
9	Low Voltage
System Communication Codes	
E	Communication Error
C	For 30 seconds after Communication established, then blank



PART NO. 37-7343B

Replaces 37-7343A
1312

White-Rodgers is a business
of Emerson Electric Co.

The Emerson logo is a
trademark and service mark
of Emerson Electric Co.

White
Rodgers™

www.white-rodgers.com
www.emersonclimate.com


EMERSON
Climate Technologies