

REPLACEMENT

AXGT

Replacement for any damaged or lost sensor. For use with models listed below *

SPECIFICATIONS

Dimensions: (Inside) .52" x .52"; (Outside) 2.52" x 2.00" x 1.75"

***Only For Use With:** RIBXJA, RIBXJF, RIBXLCJA, RIBXLCJF, RIBXLSJA, RIBXLSJF

Purpose: Can replace any damaged or lost sensor. For use with the models listed above.

