

REPLACEMENT

AXR

Replacement for any damaged or lost sensor. For use with models listed below *

SPECIFICATIONS

Dimensions: (Inside Diameter) .75"; (Outside Diameter) 2.28"

***Only For Use With:** RIBMXRA, RIBMXRF

Purpose: Can replace any damaged or lost sensor. For use with the models listed above.

