

Tech Tip – DH Series Duct Heater Coil Kits

When stretching coils measure length needed, and stretch new coil slightly shorter. The coil should be evenly stretched a minimum of 1.5 to 5 times the closed wound length. After installation, cycle with the heater and allow full operation for 5 minutes.